



Samsung Waschmaschine Türdichtung Türmanschette DC64-02750A DC64-02888 A

Ein Produkt der AS Ulm Der Pflegedoktor Artikel-Nr. 0128401.

Passende Typenzuordnungen zu den Herstellern und Ersatzteile-Bezeichnungen:

Samsung

Geräteliste:

WF0702L7V/XET	WF0702L7V/XET
WF0702L7W/XEO	WF0702L7W/XEO
WF0704F7W	WF0704F7W/XEN
WF0704W7V	WF0704W7V/XEF
WF0704W7V/YLE	WF0704W7V/YLE
WF0704Y7E	WF0704Y7E/XEN
WF0714F7W	WF0714F7W/XEN
WF0714Y7E	WF0714Y7E/XEN
WF0800NCE	WF0800NCE/XEC
WF0802LWV/XET	WF0802LWV/XET
WF0802NCE	WF0802NCE/XEC
WF0804X8E	WF0804X8E/XEU
WF0804Y8E	./.
WF10724Y8E	WF10724Y8E/XEG
WF10824Z8V/XEG	WF10824Z8V/XEG
WF10894Z8V	./.
WF1702WSV2	WF1702WSV2/XET
WF1702WSV2/XEO	WF1702WSV2/XEO



WF1702WSW2/YLV	WF1702WSW2/YLV
WF1704WPC	WF1704WPC2/YLE
WF1704WPC2	WF1704WPC2/XEF
WF1704WSE2/XEU	WF1704WSE2/XEU
WF1704WSV2	WF1704WSV2/XEE
WF1704WSV2	WF1704WSV2/YLE
WF1704WSW2	WF1704WSW2/XEE
WF1704YPC2	WF1704YPC2/XEE
WF1704YPV2	WF1704YPV2/XEN
WF1714YPV2	WF1714YPV2/XEN
WF3714YSW2/XEG	WF3714YSW2/XEG
WF3784YPV2	WF3784YPV2/XEG
WF60F4E0N0W/EO	WF60F4E0N0W/EO
WF60F4E0N0W/LE	WF60F4E0N0W/LE
WF60F4E0N2W/EN	WF60F4E0N2W/EN
WF60F4E0N2W/EO	WF60F4E0N2W/EO
WF60F4E0N2W/LE	WF60F4E0N2W/LE
WF60F4E0W0W/EO	WF60F4E0W0W/EO
WF60F4E0W0W/LE	WF60F4E0W0W/LE
WF60F4E0W2W/EO	WF60F4E0W2W/EO
WF60F4E0W2W/LE	WF60F4E0W2W/LE
WF60F4E1N2W/EO	WF60F4E1N2W/EO
WF60F4E1W2W/EO	WF60F4E1W2W/EO
WF60F4E2W0W/LE	WF60F4E2W0W/LE
WF60F4E2W2W/EO	WF60F4E2W2W/EO



WF60F4E2W2W/LE	WF60F4E2W2W/LE
WF60F4E2W2W/LP	WF60F4E2W2W/LP
WF60F4E2W2X/EO	WF60F4E2W2X/EO
WF60F4E2W2X/LE	WF60F4E2W2X/LE
WF60F4E3W2W/EO	WF60F4E3W2W/EO
WF60F4E4W2W/EO	WF60F4E4W2W/EO
WF60F4E5W2W/EO	WF60F4E5W2W/EO
WF60F4E5W2W/LE	WF60F4E5W2W/LE
WF60F4E5W2W/LP	WF60F4E5W2W/LP
WF60F4E5W2X/LE	WF60F4E5W2X/LE
WF60F4ECW2W/EO	WF60F4ECW2W/EO
WF60F4EFW0W/LE	WF60F4EFW0W/LE
WF60F4EFW2W/WS	WF60F4EFW2W/WS
WF61F4E0N2W/EN	WF61F4E0N2W/EN
WF6AF4E0W2W	WF6AF4E0W2W/EG
WF70F5E0N2W/LE	WF70F5E0N2W/LE
WF70F5E0N4W/EU	WF70F5E0N4W/EU
WF70F5E0Q4W	WF70F5E0Q4W/EG
WF70F5E0Q4W/EN	WF70F5E0Q4W/EN
WF70F5E0Q4W/WS	WF70F5E0Q4W/WS
WF70F5E0R4W	WF70F5E0R4W/EG
WF70F5E0W2W/EO	WF70F5E0W2W/EO
WF70F5E0W2W/EU	WF70F5E0W2W/EU
WF70F5E0W2W/LE	WF70F5E0W2W/LE
WF70F5E0W4W	WF70F5E0W4W/EF



WF70F5E0W4W	WF70F5E0W4W/WS
WF70F5E0W4W/EU	WF70F5E0W4W/EU
WF70F5E0W4W/LE	WF70F5E0W4W/LE
WF70F5E0Z4W/EN	WF70F5E0Z4W/EN
WF70F5E1Q4W	WF70F5E1Q4W/WS
WF70F5E1Q4W/EN	WF70F5E1Q4W/EN
WF70F5E2Q4W	WF70F5E2Q4W/WS
WF70F5E2Q4W/EG	WF70F5E2Q4W/EG
WF70F5E2Q4W/EN	WF70F5E2Q4W/EN
WF70F5E2W2W/EO	WF70F5E2W2W/EO
WF70F5E2W2W/EU	WF70F5E2W2W/EU
WF70F5E2W2W/KJ	WF70F5E2W2W/KJ
WF70F5E2W2W/LE	WF70F5E2W2W/LE
WF70F5E2W2X/EU	WF70F5E2W2X/EU
WF70F5E2W4W/EU	WF70F5E2W4W/EU
WF70F5E2W4X/EU	WF70F5E2W4X/EU
WF70F5E3P4W/EN	WF70F5E3P4W/EN
WF70F5E3U4W	WF70F5E3U4W/EF
WF70F5E3W2W/EO	WF70F5E3W2W/EO
WF70F5E3W2W/LE	WF70F5E3W2W/LE
WF70F5E3W4W/EU	WF70F5E3W4W/EU
WF70F5E4P4W/EN	WF70F5E4P4W/EN
WF70F5E4Q4W/EN	WF70F5E4Q4W/EN
WF70F5E4W2W/EO	WF70F5E4W2W/EO
WF70F5E5P4W	WF70F5E5P4W/EG



WF70F5E5P4W/EN	WF70F5E5P4W/EN
WF70F5E5Q4W/EG	WF70F5E5Q4W/EG
WF70F5E5Q4W/EN	WF70F5E5Q4W/EN
WF70F5E5U4W/EO	WF70F5E5U4W/EO
WF70F5E5U4W/LE	WF70F5E5U4W/LE
WF70F5E5U4X/LE	WF70F5E5U4X/LE
WF70F5E5W2W/EO	WF70F5E5W2W/EO
WF70F5E5W2W/LE	WF70F5E5W2W/LE
WF70F5E5W2X/EO	WF70F5E5W2X/EO
WF70F5E5W4W/EO	WF70F5E5W4W/EO
WF70F5E5W4W/LE	WF70F5E5W4W/LE
WF70F5EBP4W/EG	WF70F5EBP4W/EG
WF70F5EBP4W/EN	WF70F5EBP4W/EN
WF70F5EBU2W/LE	WF70F5EBU2W/LE
WF70F5EBW2W/LE	WF70F5EBW2W/LE
WF70F5ECQ4W/EN	WF70F5ECQ4W/EN
WF70F5ECQ4W/WS	WF70F5ECQ4W/WS
WF70F5EDQ4W/EN	WF70F5EDQ4W/EN
WF70F5EDW4X/EU	WF70F5EDW4X/EU
WF71F5E0Q4W/EN	WF71F5E0Q4W/EN
WF71F5E0Z4W/EN	WF71F5E0Z4W/EN
WF71F5E2Q4W/EN	WF71F5E2Q4W/EN
WF71F5E2Q4X/EN	WF71F5E2Q4X/EN
WF71F5E3P4W/EN	WF71F5E3P4W/EN
WF71F5E4Q4W	WF71F5E4Q4W/EG



WF71F5E5P4W	WF71F5E5P4W/EG
WF71F5E5P4W/EN	WF71F5E5P4W/EN
WF71F5E5Q4W/EN	WF71F5E5Q4W/EN
WF71F5ECW4W/EN	WF71F5ECW4W/EN
WF72F5E5P4W/EG	WF72F5E5P4W/EG
WF7AF5E0Q4W	WF7AF5E0Q4W/EG
WF7AF5E1Q4W	WF7AF5E1Q4W/EG
WF7AF5E3P4W	WF7AF5E3P4W/EG
WF7AF5E4P4W	WF7AF5E4P4W/EG
WF7AF5E5P4W	WF7AF5E5P4W/EG
WF7AF5EBP4W/EG	WF7AF5EBP4W/EG
WF7AF5ECQ4W/EG	WF7AF5ECQ4W/EG
WF802B2SAGD	WF802B2SAGD/EP
WF802B2SAWQ	WF802B2SAWQ/EC
WF802B2SAWQ	WF802B2SAWQ/EP
WF805P4SAWQ/EN	WF805P4SAWQ/EN
WF806P4SAWQ	WF806P4SAWQ/EE
WF806P4SAWQ/EN	WF806P4SAWQ/EN
WF806U4SAWQ	WF806U4SAWQ/EC
WF806U4SAWQ	WF806U4SAWQ/EF
WF806U4SAWQ/EO	WF806U4SAWQ/EO
WF806U4SAWQ/ET	WF806U4SAWQ/ET
WF806U4SAWQ/LE	WF806U4SAWQ/LE
WF80F5E0N2W/LE	WF80F5E0N2W/LE
WF80F5E0Q4W/EN	WF80F5E0Q4W/EN



WF80F5E0W2W/EO	WF80F5E0W2W/EO
WF80F5E0W2W/EU	WF80F5E0W2W/EU
WF80F5E0W2W/LE	WF80F5E0W2W/LE
WF80F5E0W4W/EU	WF80F5E0W4W/EU
WF80F5E0W4W/LE	WF80F5E0W4W/LE
WF80F5E1Q4W	WF80F5E1Q4W/EG
WF80F5E2Q4W/EG	WF80F5E2Q4W/EG
WF80F5E2Q4X	WF80F5E2Q4X/EG
WF80F5E2W4W/EU	WF80F5E2W4W/EU
WF80F5E2W4W/LP	WF80F5E2W4W/LP
WF80F5E2W4X/EU	WF80F5E2W4X/EU
WF80F5E3P4W/EN	WF80F5E3P4W/EN
WF80F5E3W2W/EO	WF80F5E3W2W/EO
WF80F5E4P4W	WF80F5E4P4W/WS
WF80F5E4P4W/EN	WF80F5E4P4W/EN
WF80F5E4Q4W/EN	WF80F5E4Q4W/EN
WF80F5E4W4W/EO	WF80F5E4W4W/EO
WF80F5E5P4W	WF80F5E5P4W/EG
WF80F5E5P4W	WF80F5E5P4W/WS
WF80F5E5P4W/EN	WF80F5E5P4W/EN
WF80F5E5Q4W/EG	WF80F5E5Q4W/EG
WF80F5E5Q4W/EN	WF80F5E5Q4W/EN
WF80F5E5U2W/EO	WF80F5E5U2W/EO
WF80F5E5U4W/EO	WF80F5E5U4W/EO
WF80F5E5U4W/EU	WF80F5E5U4W/EU



WF80F5E5U4W/KJ	WF80F5E5U4W/KJ
WF80F5E5U4W/LE	WF80F5E5U4W/LE
WF80F5E5U4W/LP	WF80F5E5U4W/LP
WF80F5E5U4X/EU	WF80F5E5U4X/EU
WF80F5E5W4W/LE	WF80F5E5W4W/LE
WF80F5E5W4W/WS	WF80F5E5W4W/WS
WF80F5E5W4X/LE	WF80F5E5W4X/LE
WF80F5EBP4W/EG	WF80F5EBP4W/EG
WF80F5EBP4W/EN	WF80F5EBP4W/EN
WF80F5EBP4W/WS	WF80F5EBP4W/WS
WF80F5ECQ4W/EN	WF80F5ECQ4W/EN
WF80F7E6P6W/EN	WF80F7E6P6W/EN
WF80F7E6U6X/EU	WF80F7E6U6X/EU
WF815P4SAWQ/EN	WF815P4SAWQ/EN
WF816P4SAWQ/EN	WF816P4SAWQ/EN
WF81F5E0Q4W/EN	WF81F5E0Q4W/EN
WF81F5E3P4W/EN	WF81F5E3P4W/EN
WF81F5E5P4W	WF81F5E5P4W/EG
WF81F5E5P4W/EN	WF81F5E5P4W/EN
WF81F5E5Q4W/EN	WF81F5E5Q4W/EN
WF81F5ECW4W/EN	WF81F5ECW4W/EN
WF81F7E6P6W/EN	WF81F7E6P6W/EN
WF86F5E5P4W/EG	WF86F5E5P4W/EG
WF8AF5E0Q4W	WF8AF5E0Q4W/EG
WF8AF5E4P4W	WF8AF5E4P4W/EG



WF8AF5E5P4W	WF8AF5E5P4W/EG
WF8AF5EBP4W/EG	WF8AF5EBP4W/EG
WF8EF5E0W4W/EU	WF8EF5E0W4W/EU
WF8EF5E0W4W/LE	WF8EF5E0W4W/LE
WF90F5E0W2W/KJ	WF90F5E0W2W/KJ
WF90F5E3U4W/EU	WF90F5E3U4W/EU
WF90F5E5P4W/EG	WF90F5E5P4W/EG
WF90F5E5P4W/EN	WF90F5E5P4W/EN
WF90F5E5U4W/EU	WF90F5E5U4W/EU
WF90F5E5U4W/WS	WF90F5E5U4W/WS
WF90F5E5U4X/EU	WF90F5E5U4X/EU
WF90F7E6P6W	WF90F7E6P6W/WS
WF90F7E6P6W/EN	WF90F7E6P6W/EN
WF91F5EBP4W/EN	WF91F5EBP4W/EN
WF91F7E6P6W/EN	WF91F7E6P6W/EN
WW60J3083LW	WW60J3083LW/LE
WW60J3283LW	WW60J3283LW/EG
WW60J3283LW	WW60J3283LW/LE
WW60J3283LW/EO	WW60J3283LW/EO
WW61J3283LW	WW61J3283LW/EN
WW70J3283KW1	WW70J3283KW1EO
WW70J3283KW1	WW70J3283KW1LE
WW70J3473KW1	WW70J3473KW1EG
WW70J3473KW1	WW70J3473KW1EN
WW70J3483KW	WW70J3483KW/WS



WW70K5210UX	WW70K5210UX/LE
WW70K5400WW	WW70K5400WW/EN
WW70K5413UX	WW70K5413UX/EU
WW70K5413WW	WW70K5413WW/EU
WW71J3473KW1	WW71J3473KW1EN
WW71K5400UW/EN	WW71K5400UW/EN
WW71K5400WW	WW71K5400WW/EN
WW80J3283KW	WW80J3283KW/LE
WW80J3470KW/EG	WW80J3470KW/EG
WW80J3473KW	WW80J3473KW/EG
WW80J3473KW	WW80J3473KW/EN
WW80J3483KW	WW80J3483KW/LE
WW80J3483KW/EG	WW80J3483KW/EG
WW80K5400UW	WW80K5400UW/WS
WW80K5400WW	WW80K5400WW/EG
WW80K5400WW	WW80K5400WW/EN
WW80K5410UX	WW80K5410UX/EU
WW80K5410WW	WW80K5410WW/EU
WW80K5413UW	WW80K5413UW/EU
WW80K5413UX	WW80K5413UX/EU
WW81J3473KW	WW81J3473KW/EN
WW81K5400WW	WW81K5400WW/EN
WW8EK5400UW	WW8EK5400UW/EG
WW8SJ3283KW	WW8SJ3283KW/KJ
WW90K5410UX	WW90K5410UX/EU



WW90K5413UX

WW90K5413UX/EU